

WATER BASED FINISHER FLOOR CLEANING PROCEDURES

The procedures listed below are designed to guide the maintenance staff in the proper day-to-day cleaning procedures of the timber sports floor surface.

DAILY PROCEDURES

Sweep the floor using a regular, soft bristle push broom, to rid the floor of sand and other grit that is tracked onto the floor.

Using an untreated scissor broom, sweep the floor the length of the floor area, shaking any collected dust and grit from the scissor broom at each end.

WEEKLY PROCEDURES

The procedure described below is intended to rid the sports floor of build-up of films left from shoes and other materials that come into contact with the floor. The solution described below will restore lustre to the floor finish and surface.

- 🍷 Mix one cup of Velocity Green Earth Cleaner in a 20 litre bucket.
**(Velocity cleaner available from Shoreline Sports Floors
www.shorelinefloors.com.au)**
- 🍷 Immerse a Enhanced Floor Cleaning Micro Fibre Towel into Velocity/water solution until it is completely wet. Wring the towel to a damp state, voiding it of excessive water.
- 🍷 Lay the Micro Fibre Towel at one corner of the floor area, place the Enhanced Floor Bar on the towel and fold the front, side and edges up into space provided for weights, place weights in the bar to hold micro fibre towel together.
- 🍷 Walk the length of the floor area, stopping the opposite end of the starting end. Moving over three feet, reverse the Micro Fibre towel and walk the floor back to the starting position
- 🍷 Reimmerse the towel into the Velocity/water solution to rid it of collected dust and dirt, wring to a damp state and repeat the above procedures, until the entire floor has been covered.
- 🍷 A live demonstration can be found on our website at www.shorelinefloors.com.au

YEARLY PROCEDURES

The procedure described below needs to be completed on an annual basis to make sure the Timber Floor surface is returning the required slip resistance to user groups and appropriate finish thickness is protecting the painted enamel line markings.

- 🌀 150grit abrade of the total floor area.
- 🌀 Vacuum and mop surface.
- 🌀 Apply one or two coats of water based polyurethane to the total floor area.

Please contact Shoreline Sports Floors in regards to the required annual maintenance. Shoreline can provide a range of cost affective maintenance packages, which will protect your facilities greatest asset.

AS NECESSARY PROCEDURES

To remove black shoe heel and sole marks, rub the mark with a rag that has been soaked in diluted Velocity Green Earth Cleaner.

Gum may be removed by using a plastic scraper and rubbing the affected area with a rag, soaked in diluted Velocity Green Earth Cleaner.

CARING FOR YOUR CUSTOM BUILT FLOOR

Protecting Your Investment

Coating System:

Your new timber floor has been finished with multiple coats of the finest Water Based Polyurethane Finisher. This finish has been specifically designed for sports building and sports usage. Caring for your coating program should include some of the following:

Protective Mats:

Entrances to the sports flooring area should have protective matting installed allowing footwear to be wiped clean and dry before entering the sports playing area.

Stones lodged within the tread of the footwear should be removed.

Footwear: Specifically designed sports footwear should be worn when on your timber sports floor.

Normal street shoes should be avoided. It is normal for the sports shoes to leave rub marks on the top of the coating; these marks may remove with normal foot traffic.

Tables and Chairs:

Any tables and/or chairs that are to be installed or positioned on the sports floor should have careful consideration shown that all protective plastic caps are fitted correctly and that there are no exposed metalwork to the feet and or legs . As these caps wear they should be replaced with new ones to help protect the coating surface.

To reduce the risk of damage, tables and chairs should be lifted and not dragged across your floor.

Sports Equipment:

Installation and removal of the sports equipment should be carried out by trained facility staff. When changing the sports equipment do not let the base of any game posts drop or slide across the timber floor as this will damage the coating program.

Wooden sports equipment should have polyurethane protective covers fitted to help minimised damage. Roller skates should utilize non marking urethane wheels and stoppers. Roller blades should utilize soft non marking urethane wheels. Protruding metalwork and bolts should be fitted with protective caps.

Please note that Shoreline Sports Floors does not recommend using vinyl sports tape on the Timber Floor surface due to the floor damage which can be caused by certain adhesives. Please contact Shoreline Sports Floors for further information.